

# SYNERGY'S

## Assembly of MultiFunnel Trap Canopy



Recommended tools: Small pliers, 15/32" (12mm) socket

- A - Canopy (1)
- B - Funnel (1)
- C - Nylon Legs (3)
- D - Canopy Pins (3)
- E - Eye bolt hardware (eyebolt, nut, small washer, large washer, nylock nut).



1. Eye bolt assembly:

- a) Screw nut onto top of eye-bolt, position small washer against top of nut;
- b) Insert eye-bolt in top of canopy. Turn canopy over, and slide large washer over eye-bolt and fasten securely with nylock nut using pliers or a socket (do not over tighten).



2. Insert double flanged side of leg (from bottom) into funnel lip. Using small pliers, pull pin towards nub on funnel lip until it snaps into place. Repeat for other legs.



3. Insert canopy pins, large side against top of canopy and snap into place.



4. Place funnel against canopy positioning large hole in funnel lip over canopy pin and twist into raised notch on canopy. Snap into place. Repeat for other pins.



5. Attach completed canopy assembly to trap body.

### Need Extra Parts?

8 Funnel Trap	P218-8
12 Funnel Trap	P218-12
16 Funnel Trap	P218-16
Dry Cup	OM100D
Wet Cup	OM100W
Regular Funnel	OM101
Bottom Funnel	OM102

Canopy Only	OM133
Canopy Assembly Kit	OM133C
Canopy Pins	OM103-3
Regular Legs	OM103-2
Nylon Canopy Legs	OM103N

All our parts can be used in any Multifunnel Trap.



**Synergy Semiochemicals Corporation**

Phone: 604 454-1122 Fax: 604 568-8502

Email: [synergy@semiochemical.com](mailto:synergy@semiochemical.com)